

### INTRODUCTION

Model	Description
AP-FIC-010A-015 FE	Standard 802.3af 15.4W output
AP-FIC-010B-015 FE	Passive 15.4W output


### PACKAGE CONTENTS

* 1x PoE injector	* 1x AC power cord
* 1x Quick Installation Guide	

### ⚠ IMPORTANT:

1. Use CAT5 or 5e UTP/STP cables.
2. AC input (100~240V/AC, 50~60Hz), for a max. consumption of 19W.

### CONNECTION



### Installation Steps:

1. Connect the included AC power cord to the injector. The Power LED (Green) should be lit.
2. Connect the Data IN port to a LAN switch using an Ethernet cable.
3. Connect the Power+Data OUT port to a powered device, i.e., IP camera, using another Ethernet cable. Make sure the PoE LED (Yellow) is lit.
4. Check if the powered device (IP camera) is working properly. An IP camera may take up to 1 or 2 minutes to power up.

All specifications are subject to change without notice.  
Copyright © 2014 VIVOTEK INC. All rights reserved.