

Assembly Instructions & General Information

Mounting: The Chassis Data Modules (CDMs) are located on the rear side of the Backplane behind the Power Entry Modules (PEMs). Remove the fixing screw and push the CDM in direction of the arrow to release the locking mechanism in the CDM slot.



Warning!


Before replacing a CDM you have to remove the resp. PEM first. Before removing a PEM, make sure that the Power Feeds of the other PEM are fully functional.

See the Shelf's User Manual and Service Manual for more specific information.

CDM in a 14/16 slot Top Fan Shelf



CDM in a 14/16 slot Top Fan Shelf



General Information:

The Chassis Data Module (CDM) is a carrier board for:

- The FRU EEPROM (24LC256)
- 3 temperature sensors (LM75)
- A Hall Effect sensor (Air filter presence).

CDM Block Diagram

