


17.03.1094

ROLINE Projector Ceiling Mount (adjust.)


Installation Instructions




Max Load: 3Kgs

Caution


1. Prior to the installation of this product, the installation instructions must be read and completely understood. Keep these installation instructions in an easily accessible location for future reference.
2. The ceiling structure must be capable of supporting at least five times the weight of the projector. If not, the ceiling structure must be reinforced.
3. Proper installation procedure by a qualified service technician must be followed, as outlined in these installation instructions. Failure to do so could result in property damage, serious personal injury, or even death.
4. Safety measures must be practiced at all times during the assembly of this product. Use proper safety equipment and tools for the assembly procedure to prevent personal injury.
5. At least two qualified people should perform the assembly procedure. Personal injury and/or property damage can result from dropping or mishandling the projector.
6. This product is intended for indoor use only. Use of this product outdoors could lead to product failure and/or serious personal injury.




1.




2.




3.




4.




5C.




Adjust torque...if necessary



5A.




5B.




6-1.

Tighten the camera




6-2.

adjust forward



6-3.

Tighten the metal piece for lock



6-4.

